



Instruction for updating JLR_IMMO device program


1. Make sure computer is connected to the network normally.
2. Open the downloaded software (see below screenshot).

 JLR_IMMO_DFU.exe

3. Connect the device with computer with USB cable. Click “ scan devices” button.



4. It shows the device No., click “online update” button.



5. “update success” pops up. The download of updates is completed.

